

DTC P0A0A - Internal Heatsink Thermistor Fault

Product Family	Fault Supported
Orion BMS [Original] (24 - 180 Cell)	YES
Orion BMS 2 (24 - 180 Cell)	YES
Orion JR [Original] (16 Cell)	YES
Orion JR 2 (16 Cell)	YES

FAULT DESCRIPTION

This error code indicates that the Orion BMS has determined that an internal hardware malfunction has occurred with the internal thermistors that monitor the internal unit temperature. These parts are not user serviceable. If this error message occurs, please download the associated freeze frame data and contact the factory or authorized dealer for assistance. Please save the freeze frame data and send it along with any other relevant information to the factory as it may be crucial for appropriately repairing the unit.

Fault Code	Fault Description	Possible Trouble Area
P0A0A	Internal thermistor fault within the BMS	 Battery Management System

FAULT BEHAVIOR

This fault **prevents cell balancing from operating** until cleared or the BMS is power cycled.

DIAGNOSTIC STEPS

1.	Download the freeze frame for the fault code using the BMS Utility.
	The BMS will normally produce a freeze frame on the "Diagnostic Trouble Codes" screen in the BMS Utility when this fault code occurs that contains a comprehensive list of BMS data parameters at the time the fault occurred. It is strongly recommended that the freeze frame be downloaded from the BMS and saved to disk before the fault is cleared again as this data may assist in the future if further diagnostics are required. Additionally this freeze frame data may be requested by Technical Support if further assistance is required.
	NOTE: Only Fault Codes with a (F) next to them have freeze frame data available for download. If there is no (F) next to the fault, there is no stored freeze frame available and this step can be skipped.
	Steps to download the Freeze Frame:
	 Connect to the BMS using the Orion BMS utility. Click the "Diagnostic Trouble Codes" tab at the top. Select the correct fault code by clicking on the ID on the left side of the screen to initiate the Freeze Frame retrieval. Once the retrieval process is complete, click the "Export (CSV)" button to save the freeze frame data to the computer disk.
2.	Contact technical support.
	Please contact the company or reseller that the BMS was originally purchased from for additional questions, warranty claims, repair requests and technical support.